## FIXTURE INSTALLATION GUIDE

Model 1SX Series (One Light G9 Base Wall Sconce120V)

1SX, Rev.3 1-10




6695 Taylor Rd. Blacklick, OH 43004 www.besalighting.com

## **CAUTION:** Turn off power to electrical box before installing


- Carefully unpack parts. Loosen Allen Head Screws (F) to release the Mounting Plate (A) from Canopy.
- 2. Secure the Mounting Plate (A) to the Electrical Supply Box with Machine Screws (B) provided.
- 3. Attach the fixture Ground wire to the supply ground and secure with Wire Nut Connector (C).
- Connect the fixture conductors to the supply conductors with Wire Nut Connectors (D) as shown:

White fixture wire to white supply wire and black fixture wire to black supply wire. Carefully push wires and wire nuts back into outlet box.

 Position the Canopy (E) over the Mounting Plate and secure by tightening the Allen Head Screws (F) with the Allen Wrench provided.



- 6. Install bulb provided (40W Max., Type G9).
- Install the Glass Shade by aligning the Threaded Adapter, that is already installed on the Glass Shade, with the Threaded Socket. Carefully turn the Glass Shade clock-wise until the Glass Shade is secured.
- 8. Restore power.



**NOTE:** Glass shown is for instructional purposes. Actual Glass may vary in shape or size

Relamp with a **LOW-PRESSURE** type lamp. Packaging of this lamp will typically indicate that it's "Suitable For Use in an Open Fixture" or marked with the symbol shown.

