FIXTURE INSTALLATION GUIDE


Models using B0044.05 Backplate (Medium Base Lamps, Wall Mount 120V) B0044.5, Rev.3 3-09




6695 Taylor Rd. Blacklick, OH 43004 www.besalighting.com

CAUTION: Turn off power to electrical box before installing

- 1. Carefully remove parts from package.
- 2. Attach the Mounting Bracket (B) to the Outlet Box (C) with two Machine Screws (D). Thread the Threaded Nipple (G) into the Mounting Bracket (F). Connect the House Ground Wire to the Bare Copper Conductor with a wirenut.
- 3. Align the circular opening on the Backplate with the Threaded Nipple on the Mounting Bracket. Push the Backplate over the Threaded Nipple until the Backplate is flush with the wall. After the Backplate appears level, carefully mark the wall at the center of the Slots (J) on the Backplate. Remove the Backplate and install the Wall Anchors (I) at the marks made.
- 4. Connect the electrical leads from the fixture to the house supply wires, black to black and white to white, and secure with wirenuts provided (E).
- 5. Align the circular opening on the Backplate with the Threaded Nipple (G) on the Mounting Bracket. Push the Backplate over the Threaded Nipple until the Backplate is flush with the wall, then secure with the Cap Nut (A) and Star Washer. Further secure the Backplate using Mounting Screws (H) through the Slots on the Backplate and with the Wall Anchors (I).





- 6. With the power still off, insert bulb of not more than the labeled wattage.
- 7. Hold the Glass Diffuser (J) close to the Backplate and align the Mounting Holes (K) on the Glass Diffuser with the Mounting Brackets (L) on the Backplate.
- 8. Install the Silicone Washer (M) on the Mounting Screws (N) and then secure the Glass Diffuser by threading the Mounting Screws through the Mounting Holes into the Mounting Brackets.
- 9. Restore power.