




IMPORTANT: Before proceeding, retrieve the **Glass Shade Installation Guide**, which is included with the stem pendant cord set.

Caution: Turn off power to electrical box before installing



1. Carefully unpack parts. Remove the Mounting Bracket (B) from the Canopy, by unthreading the Cap Nuts (F) from the Threaded Posts (A).
2. The total length of stem provided is 39 inches, plus a telescoping section. Determine the stem sections needed to achieve the desired length, then proceed with assembling the fixture. Start by carefully extending the cord through each stem section and threaded nipple, individually. Assemble the fixture by threading the stem sections together, then to the socket fitter and canopy, then tighten securely.


To shorten the cord, cut to the desired length then strip back the outer jacket and the inner conductors. When shortening the cord, the polarity should be confirmed per the Polarity Instructions below.

3. Install the provided Mounting Plate to the Outlet Box (C), as shown. Attach the house ground wire and cord green stripe conductor ground and bare copper lead and secure with provided wirenut (D). Connect the conductors from the fixture cord to the house supply wires, clear to black and white stripe to white, and secure with wirenuts provided (E). Push the wires and wirenuts into the Outlet Box.
4. Align the openings on the canopy with the Threaded Posts on the Mounting Plate. Push the canopy up over the Threaded Posts until tight to ceiling, then secure with the two Cap Nuts (F).

POLARITY INSTRUCTIONS

Using a Continuity Tester or Multimeter, confirm the following connections:

- Clear Conductor with White Stripe (Neutral/White) is connected to the Socket Screwshell. This wire is to be connected to house supply white conductor.
- Clear Conductor (Hot/Black) is connected to the Socket Center Contact. This wire is to be connected to house supply black wire.




TELESCOPING STEM ADJUSTMENT

Loosen the telescoping section by turning the knurled section to the right.

Adjust the stem length by push the stem upward.

Retighten by turning the knurled section to the right. Use a pair of pliers for a final 1/2 turn, in order to secure the selected position.



All electrical connections and the installation of this fixture must be in agreement with local codes, ordinances or the NEC (National Electric Code) or CEC (Canadian Electrical Code).
Do not connect this fixture to an electrical system that does not provide a means for equipment grounding.




IMPORTANT: For installation of pendants and wiring, please refer to the **Fixture Installation Guide** included with fixture canopy

Use With these Models:

- Tamburo 16 (4007xx) (4390xx)
- Tamburo 16v2 (4008xx) (4391xx)

1. Install bulb per label on luminaire
2. Secure Glass Shade per diagram below
3. Restore power.



All electrical connections and the installation of this fixture must be in agreement with local codes, ordinances or the NEC (National Electric Code) or CEC (Canadian Electrical Code). Do not connect this fixture to an electrical system that does not provide a means for equipment grounding.

Replacement parts for this 120V Voltage Pendant Set are as follows:

- #SP012.001.100SN - 100W 10' clear cordset with Nickel Hardware
- #P700113-SN - 39" Stem Assembly. For Bronze cordset, use "BR" in place of "SN".

INSTALLATION GUIDE

Model 1KV Series -01 (Med. Base Pendant Set 120V)




BESA LIGHTING


6695 Taylor Rd. Blacklick, OH 43004
www.besalighting.com

1KV.01, Rev.5 12-11

Caution: Turn off power to electrical box before installing




1. Carefully unpack parts. Remove the Canopy (A) from the Mounting Plate by unscrewing the three (3) Retainers. Fully remove the Retainers from the threaded nipple, then pull the canopy from the Mounting Plate.




2. Install the provided Mounting Screws (C) into the Outlet Box, leaving 1/4" of threading as shown. Pull the House Wires from the Outlet Box and extend through the center opening in the Mounting Plate (D).

Align the circular openings of the Keyhole Slots (E) with the Screws then push the Mounting Plate up over the Outlet Box. Rotate the Mounting Plate and secure with Mounting Screws.



3. Shorten the three (3) cables to the desired length by pushing the cable up through the Cable Retainers (F). Trim off the excess cable length, leaving about 3" of slack for final adjustment.


To lower the cables, push the Cable Retainer up, which will release the cable and allow it to be lowered.



4. Prior to installing the canopy, the cord length must be adjusted. Loosen the set screw on the Strain Relief (G), the feed the cord up through until reaching the desired length. Tighten the set screw until the cord is firmly in place.

NOTE: For a curvy cord appearance, leave about 25% slack for shaping of the cord


Once the cord length has been adjusted, the cord must be shortened above the canopy. When shortened, insure that there is 6" or more of wire above the canopy.



5. Attach the the bare copper fixture ground wire and bare (or green striped) ground conductor from the cord to the supply ground and secure with provided Wire Nut Connector (H). Connect the cord conductors from the fixture cord to the supply conductors with Wire Nut Connectors (J) as shown: Cord conductor with white stripe to white supply wire and clear cord conductor to black supply wire.

NOTE:

When using the clear style cord, it is advised that the installer confirm the polarity per instructions on the next page.



6. Prior to replacing the canopy, push the house wiring and wrenuts up through the center opening and into the Outlet Box.

Push the canopy up tight to the ceiling as shown, then secure with the Retainers. Do not overtighten the retainers, as this could make it difficult to remove.

Replacement parts for this 120V Voltage Pendant Set are as follows:

#T1KV300-SN.01 - 300W 10' clear cordset and 3 support cables with Nickel Hardware
For Bronze cordset, use "BR" in place "SN". For 15' cordset, place "L" after metal finish.

INSTALLATION GUIDE


Use With these Models:

- Tamburo 16 (4007xx) (4390xx)
- Tamburo 16v2 (4008xx) (4391xx)

POLARITY INSTRUCTIONS


Using a Continuity Tester or Multimeter, confirm the following connections:

- Clear Conductor with White Stripe (Neutral/White) is connected to the Socket Screws. This wire is to be connected to house supply white conductor.
- Clear Conductor (Hot/Black) is connected to the Socket Center Contact. This wire is to be connected to house supply black wire.



7. Secure Glass Shade per the diagram, then install bulb per label on luminaire.

8. Restore power.



All electrical connections and the installation of this fixture must be in agreement with local codes, ordinances or the NEC (National Electric Code) or CEC (Canadian Electrical Code). Do not connect this fixture to an electrical system that does not provide a means for equipment grounding.