

FIXTURE INSTALLATION GUIDE

Models 1WM/1WT Series (One Light G9 Vanity 120V)



BESALIGHTING


6695 Taylor Rd. Blacklick, OH 43004
www.besalighting.com

1WM-1WT, Rev.1 6-10

Caution: Turn off power to electrical box before installing

Use With these Models:

- 1WM Jamie (231807)
- 1WM Aero (272707)
- 1WT Darci (272407)
- 1WT Baaz (770107)




1. Carefully unpack parts. Loosen the three (3) Allen Head Screws (F) to release the Mounting Plate (A) from Canopy (E) using the Allen Wrench provided.
2. Secure the Mounting Plate (A) to the Electrical Supply Box with Machine Screws (B) provided.
3. Attach the fixture Ground wire to the supply ground and secure with Wire Nut Connector (C).
4. Connect the fixture conductors to the supply conductors with Wire Nut Connectors (D) as shown: White fixture wire to white supply wire and black fixture wire to black supply wire. Carefully push wires and wire nuts back into outlet box.
5. Position the Canopy (E) over the Mounting Plate (A) and secure by tightening the three (3) Allen Head Screws (F) with the Allen Wrench provided.
6. With the power still off, insert bulb of not more than the labeled wattage. Install Glass Diffuser, as shown below.

GLASS INSTALLATION:

Angle the Glass Diffuser and position the bottom into the Glassholder (G) as shown, then rotate the upper portion into the glassholder. If the glass does not seat properly, then the socket wires may be conflicting with the glass neck. Gently move the wires out of the way, then reinsert the glass. Once the Glassholder is properly seated, secure with the Retaining Screw (H).
DO NOT OVERTIGHTEN THE RETAINING SCREW.

NOTE: Glass Diffuser shown is for example purposes, the actual Glass Diffuser may be different in appearance.



All electrical connections and the installation of this fixture must be in agreement with local codes, ordinances or the NEC (National Electric Code) or CEC (Canadian Electrical Code). Do not connect this fixture to an electrical system that does not provide a means for equipment grounding.

FIXTURE INSTALLATION GUIDE

Models 2WM/2WT Series (Two Light G9 Vanity 120V)



BESALIGHTING


6695 Taylor Rd. Blacklick, OH 43004
www.besalighting.com

2WM-2WT, Rev.1 6-10

Use With these Models:

- 2WM Jamie (231807)
- 2WM Aero (272707)
- 2WT Darci (272407)
- 2WT Baaz (770107)

Caution: Turn off power to electrical box before installing



NOTE: Fixture Faceplate shown is for example purposes, the actual Fixture Faceplate may be different in appearance.


1. Carefully unpack parts. Loosen the three (3) Allen Head Screws (F) to release the Mounting Plate (A) from Canopy (E) using the Allen Wrench provided.
2. Secure the Mounting Plate (A) to the Electrical Supply Box with Machine Screws (B) provided.
3. Attach the fixture Ground wire to the supply ground and secure with Wire Nut Connector (C).
4. Connect the fixture conductors to the supply conductors with Wire Nut Connectors (D) as shown: White fixture wire to white supply wire and black fixture wire to black supply wire. Carefully push wires and wire nuts back into outlet box.
5. Position the Canopy (E) over the Mounting Plate and secure by tightening the three (3) Allen Head Screws (F) with the Allen Wrench provided.
6. With the power still off, insert bulbs of not more than the labeled wattage. Install Glass Diffusers, as shown below.

GLASS INSTALLATION:

Angle the Glass Diffuser and position the bottom into the Glassholder (G) as shown, then rotate the upper portion into the glassholder. If the glass does not seat properly, then the socket wires may be conflicting with the glass neck. Gently move the wires out of the way, then reinsert the glass. Once the Glassholder is properly seated, secure with the Retaining Screw (H).

DO NOT OVERTIGHTEN THE RETAINING SCREW.

NOTE: Glass Diffuser shown is for example purposes, the actual Glass Diffuser may be different in appearance.



All electrical connections and the installation of this fixture must be in agreement with local codes, ordinances or the NEC (National Electric Code) or CEC (Canadian Electrical Code). Do not connect this fixture to an electrical system that does not provide a means for equipment grounding.

FIXTURE INSTALLATION GUIDE

Models 3WM/3WT Series (Three Light G9 Vanity 120V)



BESALIGHTING

6695 Taylor Rd. Blacklick, OH 43004
www.besalighting.com


3WM-3WT, Rev.1 6-10

Caution: Turn off power to electrical box before installing

Use With these Models:

- 3WM Jamie (231807)
- 3WM Aero (272707)
- 3WT Darci (272407)
- 3WT Baaz (770107)

NOTE: Fixture Faceplate shown is for example purposes, the actual Fixture Faceplate may be different in appearance.




1. Carefully unpack parts. Loosen the three (3) Allen Head Screws (F) to release the Mounting Plate (A) from Canopy (E) using the Allen Wrench provided.
2. Secure the Mounting Plate (A) to the Electrical Supply Box with Machine Screws (B) provided.
3. Attach the fixture Ground wire to the supply ground and secure with Wire Nut Connector (C).
4. Connect the fixture conductors to the supply conductors with Wire Nut Connectors (D) as shown: White fixture wire to white supply wire and black fixture wire to black supply wire. Carefully push wires and wire nuts back into outlet box.
5. Position the Canopy (E) over the Mounting Plate and secure by tightening the three (3) Allen Head Screws (F) with the Allen Wrench provided.
6. With the power still off, insert bulbs of not more than the labeled wattage. Install Glass Diffusers, as shown below.

GLASS INSTALLATION:

Angle the Glass Diffuser and position the bottom into the Glassholder (G) as shown, then rotate the upper portion into the glassholder. If the glass does not seat properly, then the socket wires may be conflicting with the glass neck. Gently move the wires out of the way, then reinsert the glass. Once the Glassholder is properly seated, secure with the Retaining Screw (H).
DO NOT OVERTIGHTEN THE RETAINING SCREW.

NOTE: Glass Diffuser shown is for example purposes, the actual Glass Diffuser may be different in appearance.



All electrical connections and the installation of this fixture must be in agreement with local codes, ordinances or the NEC (National Electric Code) or CEC (Canadian Electrical Code). Do not connect this fixture to an electrical system that does not provide a means for equipment grounding.